

CONTENTS

INTRODUCTION ¹

PREFACE xvii

- 1-1 Reinforced Concrete Structures 1
- 1-2 Mechanics of Reinforced Concrete 1
- 1-3 Reinforced Concrete Members 4
- 1-4 Factors Affecting Choice of Concrete for a Structure 6
- 1-5 Historical Development of Concrete and Reinforced Concrete as Structural Materials 8
 - Cement and Concrete* 8
 - Reinforced Concrete* 8
 - Design Specifications for Reinforced Concrete* 10
- 1-6 Building Codes and the ACI Code 10

THE DESIGN ² PROCESS

- 2-1 Objectives of Design 12
- 2-2 Design Process 13
- 2-3 Limit States and the Design of Reinforced Concrete 14
 - Limit States* 14
 - Limit States Design* 15
 - Basic Design Relationship* 15
- 2-4 Structural Safety 17
- 2-5 Probabilistic Calculation of Safety Factors 20
 - Example 2-1 Computation of Theoretical Load and Resistance Factors Based on Eqs. 2-6* 22
- 2-6 Design Procedures Specified in the ACI Building Code 22
 - Factored Loads, Required Strength* 24

Example 2-2 Computation of Factored Load Effects **25**

Factored Resistance, Design Strength **26**

2-7 Loadings and Actions **26**

Direct and Indirect Actions **26**

Classifications of Loads **27**

Loading Specifications **28**

Dead Loads **28**

Live Loads Due to Use and Occupancy **29**

Snow Loads **31**

Roof Loads **31**

Construction Loadings **32**

Wind Loads **32**

Earthquake Loads **34**

2-8 Design for Economy **38**

2-9 Handbooks and Design Aids **39**

2-10 Customary Dimensions and Construction Tolerances **39**

2-11 Accuracy of Calculations **40**

3

MATERIALS

3-1 Introduction **41**

3-2 Concrete **41**

3-3 Strength of Concrete **41**

Mechanism of Cracking and Failure in Concrete Loaded in Compression **41**

Compressive Strength of Concrete **44**

Tensile Strength of Concrete **51**

Strength Under Biaxial and Triaxial Loadings **54**

3-4 Mechanical Properties of Concrete **57**

Stress-Strain Curve for Normal-Weight Concrete in Compression **58**

Stress-Strain Curve for Normal-Weight Concrete in Tension **61**

3-5 Time-Dependent Volume Changes **61**

Shrinkage **61**

Example 3-1 Calculation of Shrinkage Strains **65**

Creep **66**

Example 3-2 Calculation of Unrestrained Creep Strains **68**

Thermal Expansion **69**

3-6 Lightweight Concrete **69**

3-7 Behavior of Concrete Exposed to High and Low Temperatures **70**

3-8 Reinforcement **71**

Hot-Rolled Deformed Bars **71**

Welded-Wire Fabric **76**

4

FLEXURE:

**BASIC CONCEPTS,
RECTANGULAR
BEAMS**

4-1 Introduction **78**

Analysis versus Design **79**

Required Strength and Design Strength **79**

Positive and Negative Moments **80**

Symbols and Abbreviations **80**

4-2 Flexure Theory **81**

Statics of Beam Action **81**

Flexure Theory for Reinforced Concrete **83**

4-3	Analysis of Reinforced Concrete Beams	91
	<i>Stress and Strain Compatibility and Equilibrium</i>	91
	<i>Analysis of the Flexural Capacity of a General Cross Section</i>	92
	<i>Example 4-1 Calculation of the Moment Capacity of a Beam</i>	92
	<i>Tension, Compression, and Balanced Failures</i>	94
	<i>Analysis of Rectangular Beams with Tension Reinforcement Only</i>	96
	<i>Example 4-2 Analysis of Singly-Reinforced Beams: Tension Steel Yielding</i>	100
	<i>Example 4-2M Analysis of Singly-Reinforced Beams: Tension Steel Yielding—SI Units</i>	102
	<i>Example 4-3 Analysis of Singly-Reinforced Beams: Tension Steel Elastic</i>	104
	<i>Effect of Variables on M_n for Singly-Reinforced Beams</i>	105
4-4	Design of Rectangular Beams	106
	<i>General Factors Affecting the Design of Rectangular Beams</i>	106
	<i>Example 4-4 Calculation of d and Minimum b</i>	113
	<i>Design of Rectangular Beams with Tension Reinforcement</i>	116
	<i>Example 4-5 Design of Reinforcement When b and h Are Known</i>	117
	<i>Example 4-6 Design of a Beam for Which b and d Are Not Known</i>	121
	<i>Use of Design Aids in Rectangular Beam Design</i>	124
	<i>Example 4-7 Use of Design Aids to Design Rectangular Beam When b and d Are Not Known</i>	124
	<i>Direct Solution of Required Area of Steel</i>	125
	<i>Example 4-8 Use Eq. 4-27 to Solve for A_s</i>	125

5-1	Introduction	130
5-2	T Beams	130
	<i>Practical Applications of T Beams</i>	130
	<i>Effective Flange Width and Transverse Reinforcement</i>	132
	<i>Analysis of T Beams</i>	134
	<i>Example 5-1 Analysis of the Positive Moment Capacity of a T Beam: a Less Than h_f</i>	137
	<i>Example 5-2 Analysis of the Negative Moment Capacity of a T Beam</i>	139
	<i>Example 5-3 Analysis of a T Beam with the Neutral Axis in the Web</i>	140
	<i>Example 5-3M Analysis of a T Beam with the Neutral Axis in the Web—SI Units</i>	142
	<i>Design of T Beams</i>	144
	<i>Example 5-4 Design Reinforcement in a T Beam</i>	145
5-3	Beams with Compression Reinforcement	146
	<i>Effect of Compression Reinforcement on Strength and Behavior</i>	146
	<i>Reasons for Providing Compression Reinforcement</i>	148
	<i>Analysis of Beams with Tension and Compression Reinforcement</i>	148

SHEAR IN BEAMS

6

<i>Ties for Compression Reinforcement</i>	154
<i>Examples of the Analysis of Beams with Compression and Tension Reinforcement</i>	154
<i>Example 5-5 Analysis of a Beam with Compression Reinforcement: Compression Reinforcement Yields</i>	154
<i>Example 5-5M Analysis of a Beam with Compression Reinforcement: Compression Reinforcement Yields—SI Units</i>	156
<i>Example 5-6 Analysis of a Beam with Compression Reinforcement: Compression Reinforcement Does Not Yield</i>	157
5-4 Unsymmetrical Beam Sections or Beams Bent about Two Axes	159
<i>Example 5-7 Analysis of an Unsymmetrical Beam</i>	161
5-5 Analysis of Moment Capacity Based on Strain Compatibility	162
<i>Example 5-8 Strain Compatibility Analysis of Moment Capacity</i>	163

6-1 Introduction	169
6-2 Basic Theory	171
<i>Stresses in an Uncracked Elastic Beam</i>	171
<i>Average Shear Stress between Cracks</i>	173
<i>Beam Action and Arch Action</i>	174
<i>B-Regions and D-Regions</i>	175
<i>Shear Reinforcement</i>	176
6-3 Behavior of Beams Failing in Shear	176
<i>Behavior of Beams without Web Reinforcement</i>	176
<i>Inclined Cracking</i>	179
<i>Internal Forces in a Beam without Stirrups</i>	180
<i>Behavior of Beams with Web Reinforcement</i>	181
6-4 Truss Model of the Behavior of Slender Beams Failing in Shear	182
<i>Construction of a Plastic Truss Model</i>	183
<i>Internal Forces in the Plastic Truss Model</i>	186
6-5 Analysis and Design of Reinforced Concrete Beams for Shear—ACI Code	190
<i>Shear Failure Limit States</i>	190
<i>Strength Reduction Factor for Shear</i>	198
<i>Location of Maximum Shear for the Design of Beams</i>	199
<i>Shear at Midspan of Uniformly Loaded Beams</i>	200
<i>Lightweight Concrete</i>	201
<i>Comparison of the Truss Model and the ACI Procedure</i>	202
<i>Examples of the Design of a Beam for Shear</i>	202
<i>Example 6-1 Design of Vertical Stirrups in a Simply Supported Beam</i>	202
<i>Example 6-1M Design of Vertical Stirrups in a Simply Supported Beam—SI Units</i>	205
6-6 Hanger Reinforcement	208
<i>Example 6-2 Design of Hanger Reinforcement in a Beam—Girder Junction</i>	209
6-7 Tapered Beams	210
6-8 Shear in Axially Loaded Beams or Columns	212
<i>Axial Tension</i>	213
<i>Axial Compression</i>	213

7
TORSION

7-1 Introduction 219
Shearing Stresses Due to Torsion in Uncracked Members 219
Principal Stresses Due to Torsion 222

7-2 Behavior of Reinforced Concrete Members Subjected to Torsion 224
Skew Bending Design Method—ACI Code 224
Plastic Space Truss Design Method 228
Torsional Stiffness 232
Equilibrium and Compatibility Torsion 233
Calculation of Torsional Moments 236

7-3 Design for Torsion, Shear, and Moment—ACI Code 237
Selection of Cross Section for Torsion 238
Minimum Torsion Considered in Design 238
Maximum Torsional Moment 239
Location of Critical Section for Torsion 239
Reinforcing Details 239

7-4 Application of ACI Design Method for Torsion 241
Review of the Steps in the Design Method 241
Example 7-1 Design for Torsion, Shear, and Moment: Equilibrium Torsion—ACI Method 242
Example 7-2 Compatibility Torsion 246

8
**DEVELOPMENT,
ANCHORAGE,
AND SPLICING OF
REINFORCEMENT**

8-1 Introduction 257
Average Bond Stress in a Beam 258
Bond Stresses in an Axially Loaded Prism 259
True Bond Stresses in a Beam 260
Bond Stresses in a Pull-Out Test 260

8-2 Mechanism of Bond Transfer 262

8-3 Development Length 263
Tension Development Lengths 264
Compression Development Lengths 266
Development Lengths for Bundled Bars 266
Development Lengths for Coated Bars 266

8-4 Hooked Anchorages 267
Behavior of Hooked Anchorages 267
Design of Hooked Anchorages 269

8-5 Design for Anchorage 270
Example 8-1 Anchorage of a Straight Bar 271
Example 8-2 Development of a Bar in a Cantilever 271
Example 8-3 Hooked Bar Anchorage into a Column 272

8-6 Bar Cut-Offs and Development of Bars in Flexural Members 274
Why Bars Are Cut Off 274
Location of Flexural Cutoff Points 275
Effect of Shear on Bar Forces and Location of Bar Cutoff Points 277
Development of Bars at Points of Maximum Bar Force 278
Development of Bars in Positive Moment Regions 280

	<i>Example 8-4 Checking the Development of a Bar in a Positive Moment Region</i> 282
	<i>Effect of Discontinuities at Bar Cutoff Points</i> 283
8-7	Calculation of Bar Cutoff Points 283
	<i>General Procedure</i> 283
	<i>Example 8-5 Calculation of Bar Cutoff Points Based on Equations of Moment Diagrams</i> 284
	<i>Graphical Calculation of Flexural Cutoff Points</i> 291
	<i>Example 8-6 Use of Bending Moment Diagrams to Select Bar Cutoffs</i> 292
	<i>Bent-Up Bars</i> 297
	<i>Example 8-7 Selection of Bend-Up and Bend-Down Points</i> 297
	<i>Standard Bend and Cutoff Points</i> 298
	<i>Reinforcement Details for Beams Resisting Seismic Loads</i> 298
8-8	Splices 298
	<i>Lapped Tensile Splices</i> 298
	<i>Compression Lap Splices</i> 300
	<i>Welded, Mechanical, and Butt Splices</i> 300
9	
SERVICEABILITY	
9-1	Introduction 304
9-2	Elastic Analysis of Beam Sections 304
	<i>Calculation of EI</i> 305
	<i>Example 9-1 Calculation of the Transformed Section Properties</i> 306
	<i>Service Load Stresses in a Cracked Beam</i> 308
	<i>Example 9-2 Calculation of the Service Load Steel Stress in a Rectangular Beam</i> 309
9-3	Cracking 310
	<i>Types of Cracks</i> 310
	<i>Development of Cracks Due to Loads</i> 312
	<i>Reasons for Controlling Crack Widths</i> 315
	<i>Limits on Crack Width</i> 315
	<i>ACI Code Crack Control Provisions</i> 316
	<i>Example 9-3 Checking the Distribution of Reinforcement in a Beam</i> 316
	<i>Example 9-4 Calculation of the Maximum Bar Spacing for Bars in a One-Way Slab</i> 318
	<i>Web Face Reinforcement</i> 318
9-4	Deflections: Response of Concrete Beams 319
	<i>Load-Deflection Behavior of a Concrete Beam</i> 319
	<i>Flexural Stiffness and Moment of Inertia</i> 320
	<i>Calculation of Deflections</i> 323
9-5	Consideration of Deflections in Design 326
	<i>Limits on Deflections</i> 326
	<i>Accuracy of Deflection Calculations</i> 328
	<i>Deflection Control by Span-to-Depth Limits</i> 328
	<i>Example 9-5 Calculation of Immediate Deflection</i> 328
	<i>Example 9-6 Calculation of Deflections Occurring after Attachment of Nonstructural Elements</i> 334
9-6	Frame Deflections 335
9-7	Vibrations 335
9-8	Fatigue 336

10
**CONTINUOUS
BEAMS
AND ONE-WAY
SLABS**

- 10-1 Introduction 339
- 10-2 Continuity in Reinforced Concrete Structures 339
 - Braced and Unbraced Frames* 341
 - One-Way Slab and Beam Floors* 342
- 10-3 Moments and Shears in Continuous Beams 343
 - Pattern Loadings* 344
 - ACI Moment Coefficients* 349
 - Moment Redistribution* 351
- 10-4 One-Way Slabs 351
 - Structural Action* 351
 - Thickness of One-Way Slabs* 352
 - Cover* 352
 - Reinforcement* 353
 - Examples* 354
 - Example 10-1 Design of a One-Way Slab* 357
- 10-5 Continuous Beams 361
 - Example 10-2 Design of a Continuous T Beam* 361
- 10-6 Design of Girders 377
- 10-7 Joist Floors 378
- 10-8 Summary 380

11
**COLUMNS,
COMBINED AXIAL
LOAD, AND
BENDING**

- 11-1 Introduction 381
- 11-2 Tied and Spiral Columns 383
 - Behavior of Tied and Spiral Columns* 384
 - Strength of Axially Loaded Columns* 387
 - Spacing and Construction Requirements for Ties* 389
 - Amount of Spirals and Spacing Requirements* 392
- 11-3 Interaction Diagrams 393
 - Properties of Interaction Diagrams* 393
- 11-4 Interaction Diagrams for Concrete Columns 396
 - Strain Compatibility Solution* 396
 - Example 11-1 Calculation of an Interaction Diagram* 402
 - Interaction Diagrams for Circular Columns* 408
 - Properties of Interaction Diagrams for Reinforced Concrete Columns* 409
 - Simplified Interaction Diagrams for Columns* 411
- 11-5 Design of Short Columns 412
 - Types of Calculations—Analysis and Design* 412
 - Factors Affecting the Choice of Column* 412
 - Design Examples* 417
 - Example 11-2 Design of a Tied Column for a Given P_u and M_u* 417
 - Example 11-3 Design of a Spiral Column for a Large Axial Load and Small Moment* 420
 - Example 11-4 Design of a Tied Column for a Small Axial Load* 421
- 11-6 Contributions of Steel and Concrete to Column Strength 421
- 11-7 Approximate Solution for Tied Columns Failing in Compression 424
 - Example 11-5 Calculation of P_n Using Modified Whitney Equation* 425

Example 11-6 Using the Modified Whitney Equation to Select Reinforcement for a Column 425

11-8 Biaxially Loaded Columns 426

Example 11-7 Design of a Biaxially Loaded Column: Equivalent Eccentricity Method 428

Example 11-8 Design of a Biaxially Loaded Column: Bresler Reciprocal Load Method 430

**12
SLENDER
COLUMNS**

12-1 Introduction 432

Definition of Slender Columns 432

Buckling of Axially Loaded Elastic Columns 434

Slender Columns in Structures 436

12-2 Behavior and Analysis of Pin-Ended Columns 437

Material Failures and Stability Failures 437

Slender Column Interaction Curves 438

Moment Magnifier for Symmetrically Loaded Pin-Ended Beam Column 439

Effect of Unequal End Moments on the Slender Column Strength 440

Column Stiffness, EI 443

Effect of Sustained Loads on Pin-Ended Columns 444

Limiting Slenderness Ratios for Slender Columns 447

Summary of Moment Magnifier Design Procedure for Slender Pin-Ended Columns 447

Example 12-1 Design of a Slender Pin-Ended Column 448

12-3 Behavior of Restrained Columns in Braced Frames 452

Effect of End Restraints on Braced Frames 452

Effect of Sustained Loads on Columns in Braced Frames 456

12-4 Behavior of Restrained Columns in Unbraced Frames 457

12-5 Design of Columns in Frames 458

Design Approximation for the Effect of End Restraints 458

Definition of Braced and Unbraced Frames 464

Summary of ACI Column Design Methods 464

12-6 Design of Columns in Frames: Moment Magnifier Method 465

M_b and M_s Moments 465

Sidesway Buckling under Gravity Loads 467

Summary of Moment Magnifier Design Procedure for Slender Columns in Frames 467

Example 12-2 Design of the Columns in a Braced Frame 469

Example 12-3 Design of the Columns in an Unbraced Frame 474

Discussion of the ACI Moment Magnifier Design Procedure 485

12-7 Column Design Based on Second-Order Frame Analyses 485

Analysis Requirements 485

Methods of Analysis 488

Example 12-4 Unbraced Frame: Using Iterative P-Δ Analysis to Compute δ_sM_s 489

Example 12-5 Unbraced Frame: Using Direct P-Δ Analysis to Compute δ_sM_s 492

12-8 Modified R-Factor Method 493

12-9 General Analysis of Slenderness Effects 494

SHEAR STRENGTH OF SLABS AND FOOTINGS

- 13-1 Introduction 496
- 13-2 Behavior of Slabs or Footings Failing in Two-Way Shear 497
- 13-3 Design for Two-Way Shear 497
 - Location of the Critical Perimeter* 497
 - Design Equations: Two-Way Shear with Negligible Moment Transfer* 500
 - One-Way Shear in Slabs or Footings* 503
 - Example 13-1 Checking One-Way and Two-Way Shear at an Interior Column in a Flat Plate* 503
- 13-4 Combined Shear and Moment Transfer in Two-Way Slabs 505
 - Moment Transferred by Flexure and Shear* 506
 - Properties of the Shear Perimeter* 508
 - Calculation of Moment about Centroid of Shear Perimeter* 511
 - Example 13-2 Checking Combined Shear and Moment Transfer at an Edge Column* 513
- 13-5 Shear in Slabs: Design 516
 - Detailing of Slab Reinforcement Perpendicular to the Edge of the Slab* 516
 - Progressive Collapse Reinforcement* 517
 - Example 13-3 Design of Progressive Collapse Reinforcement* 517

FOOTINGS

- 14-1 Introduction 519
- 14-2 Soil Pressure under Footings 521
 - Limit States Governed by the Soil* 521
 - Elastic Distribution of Soil Pressure under a Footing* 522
 - Gross and Net Soil Pressures* 524
- 14-3 Structural Action of Strip and Spread Footings 526
 - Flexure* 526
 - Development of Reinforcement* 528
 - Shear* 528
 - Transfer of Load from Column to Footing* 530
 - Practical Aspects* 531
- 14-4 Strip or Wall Footings 532
 - Example 14-1 Design of a Wall Footing* 532
- 14-5 Spread Footings 534
 - Example 14-2 Design of a Square Spread Footing* 534
 - Rectangular Footings* 539
 - Example 14-3 Design of a Rectangular Spread Footing* 539
 - Footings Transferring Vertical Load and Moment* 541
- 14-6 Combined Footings 541
 - Example 14-4 Design of a Combined Footing* 543
- 14-7 Mat Foundations 550
- 14-8 Pile Caps 550

TWO-WAY SLAB SYSTEMS: BEHAVIOR AND ANALYSIS— GRAVITY LOADS

- 15-1 Introduction 552
- 15-2 History of Two-Way Slabs 554
- 15-3 Behavior of a Slab Loaded to Failure in Flexure 556
- 15-4 Statical Equilibrium of Two-Way Slabs 557
 - Nichol's Analysis of Slabs* 558
 - Example 15-1 Computation of Statical Moment, M_0* 561

15-5	Elastic Analysis of Slabs	563
	Analysis	563
	Relationship between Slab Curvatures and Moments	565
	Example 15-2 Estimation of Approximate Reinforcement Distribution from Curvatures	567
	Moments in Slabs Supported on Stiff Beams or Walls	568
	Moments in Slabs Supported on Isolated Columns	571
15-6	Yield Line Analysis of Slabs	573
	Yield Criterion	573
	Locations of Axes and Yield Lines	574
	Methods of Solution	576
	Virtual Work Method	576
	Example 15-3 Yield Line Analysis of One-Way Slab by Virtual Work	577
	Example 15-4 Yield Line Analysis of a Square Slab by Virtual Work	578
	Example 15-5 Yield Line Analysis of a Square Slab Using Virtual Work	580
	Example 15-6 Calculation of the Load Capacity of a Reinforced Concrete Slab	581
	Yield Line Patterns at Columns or Concentrated Loads	583
	Example 15-7 Calculation of the Capacity of a Fan Yield Pattern	584

16
**DESIGN OF
 TWO-WAY SLABS:
 DIRECT DESIGN
 METHOD**

16-1	Introduction	587
	Steps in Slab Design	587
	Limitations on the Use of the Direct Design Method	588
	Beam to Slab Stiffness Ratio, α	588
	Example 16-1 Calculation of α for an Edge Beam	591
	Minimum Thickness of Two-Way Slabs	592
	Distribution of Moments within Panels	593
	Example 16-2 Calculation of Moments in an Interior Panel of a Flat Plate	599
	Example 16-3 Calculation of Moments in an Exterior Panel of a Flat Plate	602
	Moments in Columns and Transfer of Moments to Columns	606
	Design of Edge Beams for Shear and Moment	608
16-2	Details and Reinforcement Requirements	609
	Drop Panels	609
	Column Capitals	609
	Reinforcement	610
	Example 16-4 Calculation of the Required Areas of Steel in a Flat Plate	611
16-3	Design of Slabs without Beams	614
	Example 16-5 Design of a Flat-Plate Floor without Spandrel Beams: Direct Design Method	614
16-4	Slabs with Beams in Two Directions	635
	Example 16-6 Design of a Two-Way Slab with Beams in Both Directions: Direct Design Method	636

EQUIVALENT FRAME METHOD

- 17-1 Introduction 651
- 17-2 Equivalent Frame Analysis of Slab Systems for Vertical Loads 652
 - Calculation of Stiffness, Carryover, and Fixed-End Moments* 652
 - Properties of Slab-Beams* 653
 - Example 17-1 Calculation of the Moment Distribution Constants for a Flat Plate Floor* 656
 - Example 17-2 Calculation of the Moment Distribution Constants for a Two-Way Slab with Beams* 657
 - Properties of Columns* 658
 - Torsional Members and Equivalent Columns* 659
 - Example 17-3 Calculation of K_t , ΣK_c , K_{ec} for an Edge Column and an Interior Column* 663
 - Example 17-4 Calculation of K_{ec} for an Edge Column in a Two-Way Slab with Beams* 665
 - Arrangement of Live Loads for Structural Analysis* 667
 - Moments at the Face of Support* 668
 - Division of Moments to Column Strips, Middle Strips, and Beams* 669
 - Selection of Slab Thickness* 669
 - Example 17-5 Design a Flat-Plate Floor Using the Equivalent Frame Method* 669
- 17-3 Use of Computers in the Equivalent Frame Method 676
- 17-4 Equivalent Frame Analysis of Laterally Loaded Unbraced Frames 677

SHEAR FRICTION, DEEP BEAMS, CORBELS, DISCONTINUITY REGIONS, AND JOINTS

- 18-1 Introduction 679
- 18-2 Shear Friction 679
 - Behavior in Tests* 679
 - Design Rules in the ACI Code* 682
 - Example 18-1 Design the Reinforcement in the Bearing Region of a Precast Beam* 685
- 18-3 Horizontal Shear 685
- 18-4 Deep Beams 687
 - Analyses and Behavior of Deep Beams* 688
 - Design of Deep Beams* 692
 - Design by the Plastic Truss Model* 692
 - Example 18-2 Design a 36-ft-Span Transfer Girder* 699
 - Deep Beam Design for Shear by the ACI Code* 707
- 18-5 Brackets and Corbels 708
 - Structural Action* 709
 - Design of Corbels* 710
 - Example 18-3 Design of a Corbel* 711
- 18-6 D-Regions 714
 - Basic Method of Solution of D-Regions* 714
 - Example 18-4 Design of D-Regions* 715
- 18-7 Beam-Column Joints 717
 - Corner Joints: Opening* 718
 - Corner Joints: Closing* 719

	<i>T-Joints</i> 720
	<i>Beam-Column Joints in Frames</i> 721
	<i>Design of Joints According to ACI 352</i> 722
	<i>Example 18-5 Design of Joint Reinforcement</i> 724
	<i>Joints between Wide Beams and Narrow Columns</i> 726
18-8	Bearing Strength 727
	<i>Internal Forces near Bearing Areas</i> 727
	<i>ACI Code Requirements for Bearing Areas</i> 728
	APPENDIX A DESIGN TABLES 731
	APPENDIX B NOTATION 760
	INDEX 785