

# *Table of Contents*



## INTRODUCTION

### *Section One*

## GENERAL COMMUNICATIONS

### DEFINITIONS

## **1** COMMUNICATION

Introduction | 1-1

1.1 Q-Codes Used in R/T Air Ground Communication | 1-1

1.2 Procedures for Obtaining Bearing Information In-Flight | 1-2

1.3 Categories of Messages | 1-3

1.4 General Principles of VHF Propagation and Allocation of Frequencies | 1-5

## **2** GENERAL OPERATING PROCEDURES

Introduction | 2-1

2.1 Radio Transmitting Technique | 2-1

2.2 Transmission of Letters | 2-2

2.3 Transmission of Numbers | 2-4

2.4 Transmission of Time | 2-8

2.5 Indication of Transmitting Frequency on HF (High Frequency) | 2-9

2.6 Standard Words and Phrases | 2-9

## 3 CALL SIGNS

Introduction | 3-1

3.1 Call Signs for Aeronautical Stations | 3-1

3.2 Aircraft Call Signs | 3-2

3.3 Change of Call Sign | 3-3

### *Section Two*

## VFR COMMUNICATIONS

## 4 TRANSFER OF COMMUNICATIONS

Introduction | 4-1

4.1 Transfer of VHF Communications | 4-1

4.2 Transfer of HF Communications | 4-1

4.3 Procedure for Transfer of Communication | 4-2

4.4 Test Procedures and Readability Scale | 4-2

4.5 Issue of Clearance and Read Back Requirements | 4-3

4.6 Conditional Phrases | 4-6

4.7 Reporting Flight Conditions | 4-7

4.8 Weather Deviation Required | 4-7

## 5 VFR

Introduction | 5-1

5.1 Aerodrome Procedures | 5-1

5.2 VFR Departures | 5-16

5.3 VFR Arrivals | 5-17

5.4 Radar Procedural Phraseology | 5-18

## 6 AERODROME WEATHER

Introduction | 6-1

6.1 Routine and Special Reports | 6-1

6.2 Wind Direction and Speed | 6-2

6.3 Visibility | 6-3

6.4 Present Weather | 6-4

6.5 Cloud Amount and Type | 6-8

6.6 Air Temperature and Dew-Point | 6-9

6.7 Pressure Values | 6-9

6.8 Supplementary Information | 6-10

6.9 Weather Broadcast | 6-11

6.10 Aerodrome Conditions | 6-11

## 7 COMMUNICATION FAILURE

Introduction | 7-1

7.1 Air-Ground Radio Failure | 7-1

7.2 Receiver Failure | 7-2

7.3 Transponder Code 7600 | 7-2

7.4 Ground-to-Air Relay Communication Technique | 7-3

## 8 DISTRESS AND URGENCY PROCEDURES

Introduction | 8-1

8.1 Distress and Urgency Definitions | 8-1

8.2 Frequency | 8-2

8.3 Emergency SSR Codes | 8-4

8.4 Distress Messages | 8-4

8.5 Urgency Messages | 8-6

8.6 Emergency Descent | 8-8

### *Section Three*

## IFR COMMUNICATIONS

### 9 IFR

Introduction | 9-1

9.1 General Operating Procedures, IFR | 9-1

9.2 IFR Departures | 9-5

9.3 En-Route Clearances | 9-8

9.4 Position Reporting | 9-11

9.5 IFR Arrivals | 9-13

9.6 IFR Clearance | 9-25

9.7 Level Changes and Reports | 9-29

9.8 RVSM Operations | 9-31

### 10 COMMUNICATION FAILURE IFR

Introduction | 10-1

10.1 Air-Ground Communication Failure | 10-1

10.2 Additional Procedures | 10-4

### 11 DISTRESS AND URGENCY

Introduction | 11-1

11.1 Definitions | 11-1

11.2 Distress Messages | 11-3

11.3 Urgency Messages | 11-6

11.4 PAN Medical Procedure | 11-7

## 12 AERODROME WEATHER, IFR

Introduction | 12-1

12.1 Runway Visual Range, (RVR) | 12-1

12.2 Runway Conditions | 12-2

12.3 Braking Action (B/A) | 12-3

12.4 Reporting of Routine Weather | 12-3

12.5 Special Air-Reports | 12-4

12.6 Special Aircraft Observations | 12-4

12.7 Other Non-Routine Aircraft Observations | 12-5

## 13 MISCELLANEOUS FLIGHT HANDLING

Introduction | 13-1

13.1 Selective Calling (SELCAL) | 13-1

13.2 TCAS | 13-2

13.3 FANS Future Air Navigation Systems | 13-6

13.4 ACARS Aircraft Communication Addressing and Reporting System | 13-10

13.5 Surveillance | 13-12

13.6 Morse Code | 13-14

## ABBREVIATIONS

## EASA SYLLABUS INDEX